

### **ACID CLEANER AND ANTI-SLIP TREATMENT**

#### **USES**

- Suitable for homogeneous tiles, cement floors, marble, granite and pebble stone surfaces.
   (Not suitable for printed pattern ceramic tiles as it will etch away the surface layer.)
- 2. **AS17** etching treatment is an invisible floor treatment, not a coating.

#### **APPLICATION METHOD**

- 1. Dilute **AS17 with 1 volume of water,** wet the floor and spread with PVC mop.
- 2. **AS17** will etch the tile surface in about 20 minutes to increase the slip resistance.
- 3. Test by stepping on it to feel the slip resistance.
- 4. After treatment, rinse immediately with water.
- 5. Do not over-etch; it will roughen the floor with the tendency to trap dirt and stain.

**COVERAGE** 16 m<sup>2</sup> / liter

PACKING 1-kg bottle, 5-kg carboy, 10-kg carboy, 20-kg jerry can



Product used on toilet floor at Ngee An Polytechnic.



Anti-slip test reading above 40—possibility of slip is extremely low.



#### **WARRIOR PTE LTD**

Blk 17 Marsiling Industrial Estate Road 1 # 01-11 Singapore 739279

Tel: (65) 6364 5100 , 6364 5060 , 6367 3676

war99@singnet.com.sq www.warrior.com.sq





## **ACID CLEANER AND ANTI-SLIP TREATMENT**

#### **CLEANING AND MAINTENANCE**

- 1. Simply keep it free of dirt and oil.
- 2. Do not apply wax or apply glossing solutions containing wax to a treated floor.
- 3. Wax will increase the chances of slip and falls.
- 4. After a few years, can maintain the frictional resistance by add 10% **AS17** into the Detergent to mop the floor.

#### **CAUTION**

- 1. Will whiten or dull black or dark-coloured tiles or stone surfaces.
- 2. Test on a small area to check for colour changes before treating the whole area.
- 3. **Corrosive**; will corrode stainless steel, aluminum and glass.

#### **SAFETY PRECAUTIONS**

- 1. Wear nitrile gloves, gumboots and safety goggles.
- 2. Skin contact: It will penetrate the skin. Wash immediately with soap and plenty of water.
- 3. Eye contact: Flush the eye for 15 minutes with plenty of water and seek medical attention

immediately.

#### **STORAGE**

Keep in the original containers. Do not switch to other containers. Make sure the cap is closed tightly.

Above are our recommendations based on in-house testing and experience. When in doubt, please do a preliminary testing on-site before use.



#### **WARRIOR PTE LTD**

Blk 17 Marsiling Industrial Estate Road 1 # 01-11 Singapore 739279

Tel: (65) 6364 5100 , 6364 5060 , 6367 3676

war99@singnet.com.sg www.warrior.com.sg





### **ACID CLEANER AND ANTI-SLIP TREATMENT**

NOTE – Recommendations for the selection of pedestrian surface materials (in terms of the minimum pendulur or ramp specifications) for some specific locations are given in Annex E.

Table 2 - Wet pendulum test classification

Classification	Mean British Pendulum Number (BPN)		Notional <sup>†</sup> contribution of floor surface to the risk of slipping when wet
	Four S rubber*	TRL rubber*	
V	> 54	> 44	Very low
W	45 to 54	40 to 44	Low
Х	35 to 44	-	Moderate
Y	25 to 34	_	High
Z	< 25	-	Very high

<sup>\*</sup> While either of these rubbers may be used, the test report shall specify which rubber was used.

NOTE – It is expected that these surfaces will have greater resistance when dry.

Table 3 - Dry floor friction test classification

Classification	Floor friction tester mean value	Notional <sup>†</sup> contribution of floor surface to the risk of slipping when dry
F	≥ 0.4	Moderate to very low
G	< 0.4	High to very high

#### Disclaimer:

The information provided in this brochure is ensured to be as accurate as possible at the time of inclusion, however there may be inadvertent and occasional errors which may have slipped from our notice. Warrior Pte Ltd does not guarantee and make no representations or warranties of any kind about the information, advice and opinions provided and reserves the right to make changes and corrections at any time, without prior notice to any parties. Warrior Pte Ltd accepts no liability for any inaccuracies or omissions in its brochure and any decisions made based on information and opinions contained in the brochure is the sole responsibility of the user.

#### **WARRIOR PTE LTD**

Blk 17 Marsiling Industrial Estate Road 1 # 01-11 Singapore 739279

Tel: (65) 6364 5100, 6364 5060, 6367 3676

war99@singnet.com.sg www.warrior.com.sg



<sup>&</sup>lt;sup>†</sup> The term 'notional' has been used to highlight the need to consider all potential contributing factors to a slincident.



## **ACID CLEANER AND ANTI-SLIP TREATMENT**



Safe high reading of 88. Reading above 40 is safe.



Scrub the floor with AS17. Wear goggles and gloves to protect yourself.





After treatment, free calcium may flow out from the cement joint. It can be removed by scrubbing. Suggest pre-treating the joint with SS10 before AS17 treatment.

#### **WARRIOR PTE LTD**

Blk 17 Marsiling Industrial Estate Road 1 # 01-11 Singapore 739279

Tel: (65) 6364 5100 , 6364 5060 , 6367 3676

war99@singnet.com.sg www.warrior.com.sg

